Signet 3519 Flow Wet-Tap Valve





Description

The Signet 3519 Flow Wet-Tap Valve serves as a unique interface between the installation fitting and the wet-tap style Signet 515 or 2536 Rotor-X flow sensor. It provides a fast method of removing the sensor from the pipe under specified operating pressures. The PVC and stainless steel design of the Wet-Tap makes it resistant to corrosion and chemical attack by acids, alkalies, salt, and a number of other harsh chemicals.

The Signet 3519 Wet-Tap Valve mounts directly onto standard Signet installation fittings. The 3519 Wet-Tap consists of a flange and support plate that threads onto the pipe fitting insert, and a PVC ball valve through which an extended length sensor is inserted into the pipe.


Features

- Allows sensor removal without process shutdown
- Pressure release valve for safe sensor removal
- Dual safety lanyards
- Rugged corrosionresistant PVC construction and stainless steel hardware
- Compatible with Signet 515 or 2536 Rotor-X Wet-Tap Flow Sensors
- Eliminates process downtime

Applications


- Filtration Systems
- Chemical Production
- Pump Protection
- Scrubbers
- Water Distribution
- Effluent Totalization
- Process Cooling Loops


System Overview




^{*}See Fittings section for more information.


Dimensions





Model 515 or 2536 Wet-Tap Sensor





Please refer to Wiring, Installation, and Accessories sections for more information.

Specifications

General

Body: PVC Ball Seat: PTFE

Seals: FPM (std) or EPR (EPDM)

also available, contact

factory

Hardware: 302/304SS (brackets),

18/8SS (nuts & bolts)

Max. Pressure/Temperature Rating

7 bar max. @ 20 °C (100 psi max. @ 68 °F)

 1.4 bar max. @ 66 °C (20 psi max. @ 150 °F)

Wet-Tap Maximum Installation/Removal Rating:

1.7 bar @ 22 °C (25 psi @ 72 °F)

Shipping Weight 1.3 kg 2.86 lb

Standards & Approvals

 Manufactured under ISO 9001 for Quality and ISO 14001 for Environmental Management

See Temperature and Pressure graphs for more information.

Application Tips

- Once installed, sensor insertion and removal can be performed without process shutdown; see installation/ removal pressure specifications page.
- Use the Conduit Adapter Kit when used in outdoor environments. See Accessories section.
- For liquids containing ferrous particles, use Signet Magmeters.
- Use sensors with sleeved rotors in abrasive liquids to reduce wear.
- For systems with components of more than one material, maximum temperature and pressure specifications must always be referenced to the component with the lowest rating.

Ordering Information

Components

3519/515-P3

3519/515-P4

3519/515-P5

3-3519

Part Number			
3-3519	Wet-Tap Valve for 515 and 2536 Wet-Tap flow sensors		
	Flow Range		
	N/C	Valve only	
	515-P3*	Valve with Model 515 sensor for ½ to 4 inch pipes	
	515-P4*	Valve with Model 515 sensor for 5 to 8 inch pipes	
	515-P5*	Valve with Model 515 sensor for 10 to 36 inch pipes	
	2536-P3**	Valve with Model 2536 sensor for ½ to 4 inch pipes	
	2536-P4**	Valve with Model 2536 sensor for 5 to 8 inch pipes	
	2536-P5**	Valve with Model 2536 sensor for 10 to 36 inch pipes	
🔻	\ \		
3-3519		Example Part Number - Valve Only	
3-3519	/515-P3	Example Part Number - Valve with Sensor	

	_
Mfr. Part No./Code	Comp
159 000 757	3519/
159 000 819	3519/
159 000 820	3519/
159 000 821	

Model 3519 Ordering Notes

- 1) N/C = no code needed.
- 2) *See model 515 data sheet for sensor specifications.
- 3) **See model 2536 data sheet for sensor specifications.
- 4) Models 515 and 2536 Wet-Tap sensors can be ordered separately.

Components	Mfr. Part No./Code
	159 000 822
3519/2536-P4	159 000 823
3519/2536-P5	159 000 824